


KV-1442

RM-651

SERVICE MANUAL

Model

Chassis No. SCC-788A-A



July, 1986

XE-5 CHASSIS

SPECIFICATIONS

Note: The service manual for RM-651 has been issued separately.

Television system	CCIR system B, G and H
Color system	PAL/SECAM
Channel coverage	VHF channels E2 - S20 UHF channels E21 - E68 (a total of up to 30 preselected channels)
Picture tube	Trinitron tube Approx. 36.8 cm (14 inches) 90 degree deflection (Approx. 33.7 cm picture measured diagonally)
Antenna	75-ohm standard coaxial socket VHF telescopic antenna (supplied)
Speaker	7.5 cm dia.
Audio output	1.5 W
Input/output	21-pin connector, Euro AV with the requirement of CENELEC standard
Power requirements	220 - 240 V AC, 50 Hz
Power consumption	69 Wh 16 Wh in standby condition
Dimensions	Approx. 366 × 356.5 × 408.5 mm (w/h/d)
Weight	Approx. 11.7 kg

Accessories supplied

Remote Commander RM-651 with 2 batteries
(IEC designation R6, size AA)
VHF telescopic antenna (1)
Antenna connector (300 - 75 ohm matching transformer is built-in.) (1)

Optional accessory

Teletext adaptor OPK-113
Connecting cable RC-113

Design and specifications are subject to change without notice.



TRINITRON® COLOR TV

SONY®

CTV

TABLE OF CONTENTS


<u>Section</u>	<u>Title</u>	<u>Page</u>
1. GENERAL		
1-1.	Location of Controls	3
1-2.	Programming	4
1-3.	Operation	6
2. DISASSEMBLY		
2-1.	Picture Tube Removal	10
2-2.	Installation of Back Cover	11
2-3.	Service Position for B Board	11
3. OPK-113 ATTACHING		12
4. SET-UP ADJUSTMENTS		
4-1.	Beam Landing	13
4-2.	Convergence	14
4-3.	Focus (RV707)	15
4-4.	White Balance	15
5. EXPLODED VIEWS		
5-1.	Picture Tube	16
5-2.	Bezel Assy	17
6. ELECTRICAL PARTS LIST		18

SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SECTION 1 GENERAL


1-1. LOCATION OF CONTROLS



1-2. PROGRAMMING

Automatic and manual programming are available. Automatic programming presets up to 30 receivable channels automatically from the lowest frequency to the highest. With manual programming the active channels can be preset in any desired sequence.

Panel opened



AUTOMATIC PROGRAMMING

- 1 Depress ①.
- 2 Press ← on the Commander if the ← indication is displayed on the screen.
- 3 Make sure that COLOR SYSTEM is set to AUTO.
- 4 Press PRESET (ON) to set the TV in the programming standby mode. The program number will blink and the band indicator will appear on the screen.
- 5 With PROGR +/- or the program number buttons on the Commander, select the program position from which automatic programming begins.
- 6 Press AUTO.
Automatic programming will start to tune in all receivable channels in sequence. When no more station can be located, the program number from which the automatic programming started will light on the screen and automatic programming will stop. The programming mode will be cancelled automatically.

MANUAL PROGRAMMING

- 1 Depress ①.
- 2 Press ← on the Commander if the ← indication is displayed on the screen.
- 3 Make sure that COLOR SYSTEM is set to AUTO.
- 4 Press PRESET (ON) to set the TV in the programming standby mode. The program number will blink and the band indicator will appear on the screen.
- 5 Press PROGR +/- or the program number buttons on the Commander to select the program position where a channel is to be tuned in:
+ for a higher-numbered position, and - for a lower-numbered position.
- 6 Press + or - MANUAL/FINE.
The first channel found will appear. Every time you press + MANUAL/FINE, a higher-numbered channel will be tuned in and every time you press - MANUAL/FINE, a lower-numbered channel will be tuned in. Repeat pressing until the desired channel is found.


Repeat steps 5 and 6 for all desired channels.

- 7 Press PRESET (OFF).

To reset the TV to the lowest frequency of the band, press CLEAR when PRESET is set to ON.

ON-SCREEN DISPLAY WHILE TUNING

The band in which the channel is being tuned in and a bar will appear. The length of the bar shows the approximate position of the channel being tuned in within the band.



FINE-TUNING OF A WEAK STATION

If the picture of a particular channel is not acceptable, make sure PRESET is set to OFF (the band indicator does not appear on the screen), and keep + or – MANUAL/FINE pressed until the picture becomes clearer. When either MANUAL/FINE is pressed, the automatic fine tuning on the selected channel is deactivated and the AFT ON indicator goes off. To view this particular channel, keep the automatic fine tuning deactivated. (Do not press AFT.) When other channels are selected, the automatic fine tuning activates automatically.

SKIPPING UNUSED PROGRAM POSITIONS

- 1 Press PRESET (ON) when the program number display shows an unused position. The program number will blink.
- 2 Press CLEAR.
- 3 Press PRESET (OFF).


Later, when you press PROGR +/-, the unused positions will be skipped.

1-3. OPERATION


VIEWING TV PROGRAM

Usually the Remote Commander is all that is needed to operate the TV in everyday use.

RM-651 Remote Commander



Picture adjustments



Press **⦿**: + to increase picture contrast or – to decrease it.
Press **⊕**: + for more color intensity or – for less color intensity.


When **⦿** or **⊕** on the Commander is pressed, the bar indication will appear on the screen; longer as the + button is pressed and shorter as the – button is pressed.

Turn **☀** clockwise for more brightness or counterclockwise for less brightness.

Turn **⦿** to stabilize the picture if it rolls vertically.

To return the picture contrast and color intensity to the factory setting, press **↔** on the Commander.

Operation



1 Depress ① to turn on the TV.

2 Press if the indication is displayed on the screen.

3 Set COLOR SYSTEM to AUTO.

In case the color is not displayed correctly, set COLOR SYSTEM to PAL or SECAM according to the color system being used.

4 Pointing the head of the Commander towards the remote control detector on the TV, select the TV program in either of two ways:

• **Press the program number buttons.**

For 1 through 9, press the corresponding single-digit button.

For 10 through 19, press "1-" for the tens-digit and then the corresponding single-digit button.

For 20 through 29, press "2-" and then the corresponding single-digit button.

For 30, press "0".

If you do not press a single-digit button within several seconds after pressing "1-" or "2-", the previous program position will be recalled.

• **Press + or - PROGR.**

5 Adjust the volume by pressing + or - : + for more volume and - for less volume.

When is pressed, the bar indication will appear.

The bar will be longer as the + button is pressed, or shorter as the - button is pressed. The indication will disappear when the button is released, then the setting will be memorized.

To set the TV to standby mode, press on the Commander.

The indicator on the TV will light brighter. When the TV is in standby mode, you can turn on the TV by pressing any of the program number buttons on the Commander.

To turn off the TV completely, press ① on the TV.

The TV can no longer be operated with the Commander.

To mute the sound immediately, press .

The indication appears on the screen.

Press it again to restore the sound.


Note

To view the picture of the equipment connected to the 21-pin connector, press so that the indication appears on the screen. Then, operate the connected equipment.

VIEWING TELETEXT

The teletext service can be received by installing the optional Sony OPK-113 teletext adaptor with the optional Sony RC-113 connecting cable.

The buttons on the Commander used for teletext operation are indicated in green.



Operation

- 1** Select the TV channel for the desired teletext service.
- 2** Press TEXT/MIX to display the teletext service.
Once TEXT/MIX has been pressed, the TV channel cannot be changed.
- 3** Key in the three digits for the desired page using the number buttons. If an error is made, complete the three-digit sequence by keying in any digit. Then, re-enter the correct page number.
The requested teletext page is displayed.

To return to the TV mode, press TV.

The teletext service can be displayed directly from the standby mode, by pressing TEXT/MIX.

To receive the teletext service of a different TV channel

- 1** Press TV to return to the TV mode.
- 2** Select the desired TV channel.
- 3** Press TEXT/MIX.

Notes

- To receive the teletext service accurately, keep AFT inside the panel switched on during teletext operation.
- During teletext operation, do not input the RGB signals from the equipment, such as a microcomputer, connected to the 21-pin connector.

To display the index page

Press INDEX.

If the necessary signal is not being broadcast, page 100 is displayed.

To rapidly access the next or preceding page

Press PAGE + or PAGE -.

To superimpose the teletext display on the TV picture

Press TEXT/MIX.

Press again to return to the TEXT display.


To suppress the teletext display so that the TV picture is displayed

Press TEXT CL.

This button can be operated from both the TEXT and MIX displays.

To prevent a teletext page (subpage) from being updated/changed

Press HOLD. "HOLD" appears at the top of the screen.



To resume normal teletext reception, press TEXT/MIX.

To enlarge the teletext display

Press / / .

Press once to enlarge the upper half of the display; press again to enlarge the lower half of the display; press again to return to the normal display.

To reveal concealed information such as the answers to a quiz

Press REVEAL.

Press again to conceal the answers.


To adjust the contrast of the teletext display

Press .

To watch the TV program while waiting for a requested page to be displayed

- 1 Request a new page.
- 2 Press TEXT CL to watch the TV program. The requested page number appears at the top left of the screen.

When the requested page has been captured, "FOUND" (or if the requested page is a subpage, "UPDATE") appears at the top of the screen.




To view this page, press TEXT/MIX.

To have a requested page displayed at a predetermined time


- 1 Request a time coded page (e.g. alarm page).
- 2 Press TP ON.

"T*:*:*" will appear at the top of the screen.



- 3 Enter your request time with the number buttons, using four digits.

For example, 07:30.



To watch the TV program until the requested time, press TEXT CL.


At the requested time, "FOUND" (or if the requested page is a subpage, "UPDATE") appears on the screen.

To view this page, press TEXT/MIX.


To cancel the request, first ensure that the teletext page is displayed, then press TP OFF.

SECTION 2 DISASSEMBLY

2-1. PICTURE TUBE REMOVAL




• Removing Procedures




2-2. INSTALLATION OF BACK COVER

Note: Insert each section A of the back cover into the section B of the B block ass'y.



2-3. SERVICE POSITION FOR B BOARD





SECTION 3 OPK-113 ATTACHING

Preparation

- RC-113 (Shield case, Connecting cable, Wire, purse lock)

Before installing the adaptor, unplug the set from the wall outlet.

1. Remove the back cover.
2. Pull out the main B board.
3. Install shield case on OPK-113.
4. Connect wire (soldering) between shield case and negative terminal of C004 on V board. (Fig. 3-1)
5. Install OPK-113 on bracket.
6. Connect to the same number terminal as the connector. (Fig. 3-2)
7. Attach the back cover.



SECTION 4

SET-UP ADJUSTMENTS

The following adjustments should be made when a complete realignment is required or a new picture tube is installed.

These adjustments should be performed with rated power supply voltage unless otherwise noted.

Controls and switch should be set as follows unless otherwise noted:

- picture control maximum
- ☀ brightness control maximum
(fully clockwise)

Perform the adjustments in order as follows:

- 4-1. Beam Landing
- 4-2. Convergence
- 4-3. Focus (RV707)
- 4-4. White Balance

Note: Test Equipment Required.

- 1. Color-bar/Pattern Generator
- 2. Degausser

4-1. BEAM LANDING

1. Input a raster signal with the pattern generator.
PICTURE . . . normal
BRT center click
2. Turn the raster signal of the pattern generator to red.
3. Move the deflection yoke backward, and adjust with the purity control so that red is in the center and blue and green are at the sides, evenly. (Fig. 4-1)
4. Move the deflection yoke forward, and adjust so that the entire screen becomes red. (Fig. 4-2)
5. Switch over the raster signal to blue and green and confirm the condition.
6. When landing at the corners is not right, adjust by using the magnet. (Fig. 4-3)
7. When the position of the deflection yoke is determined, tighten it with a deflection yoke mounting screw.




Fig. 4-1.




Fig. 4-2.





Fig. 4-3.

4-2. CONVERGENCE


Preparation:

- Before starting, perform FOCUS, H.SIZE, V.SIZE and V.LIN adjustments.
- Turn BRIGHTNESS control fully counterclockwise and PICTURE control to normal.
- Feed in the dot pattern.





(1) Horizontal and Vertical Static Convergence



1. Adjust H.STAT VR to coincide red, green and blue dots on the centre of screen (Horizontal movement)
 2. Adjust V.STAT magnet to coincide red, green and blue dots on the centre of screen (Vertical movement)
 3. If the red, green and blue dots do not coincide on the centre of screen with H.STAT VR, perform horizontal convergence adjustment using H.STAT VR and V.STAT magnet as shown below. (In this case, H.STAT VR and V.STAT magnet effect each other.)
- Tilt the V.STAT magnet and adjust static convergence to open or close the V.STAT magnet.



4. When the V.STAT magnet is moved in the direction of arrow (a) and (b), Red, Green and Blue dots move as shown below.




If blue dot does not coincide with red and green dots, perform following steps.

Move BMC magnet (a) to correct insufficient H. static convergence.

Rotate BMC magnet (b) to correct insufficient V. static convergence.


In either case, repeat Beam Landing Adjustment.



(2) Dynamic Convergence Adjustment

Preparation:

- Before starting, perform Horizontal and Vertical Static Convergence Adjustment.
1. Loosen deflection yoke screw.
 2. Remove deflection yoke spacers.
 3. Move the deflection yoke for best convergence as shown below.
 4. Tighten the deflection yoke screw.
 5. Install the deflection yoke spacers.



4-3. FOCUS (RV707)

Adjust Focus VR(RV707) for a best Picture.

4-4. WHITE BALANCE

[SCREEN (G₂)]

1. Input a dots pattern.
2. Set the PICTURE control at minimum and turn the BRIGHT control fully counterclockwise.
3. Confirm that BKG voltage is 160V dc when turning RV701 (R.BKG), RV703 (G.BKG) and RV705 (B.BKG).
4. Note the color which becomes visible first when turning RV706.

[WHITE BALANCE (Cut off)]

1. Input a all white signal.
2. Set the PICTURE control to minimum and turn the BRIGHT control center click.

3. Turn RV704 (B.DRIVE) and RV702 (G.DRIVE) fully clockwise.
4. Set RV701 (R.BKG), RV703 (G.BKG) and RV705 (B.BKG) to minimum.
5. Turn RV709 (SUB BRT) slowly to obtain a faintly visible cross-hatch.
Note the color that first becomes visible by turning RV709.
Do not turn a BKG control for this color.
6. Adjust the other two BKG controls for best white balance (neutral gray) of the faint cross-hatch.
7. Set the PICTURE control fully clockwise.
Observe the screen and adjust the DRIVE controls for best white balance.
8. Repeat steps 5, through 7.

SECTION 5 EXPLODED VIEWS


NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

5-1. PICTURE TUBE

▲: TA, BV4x16 7-685-663-71




No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
1	4-374-921-61	HANDLE (LEFT)		9	4-365-808-00	SCREW (5), TAPPING	
2	4-374-920-31	HANDLE (RIGHT)		10	*4-346-339-00	HOLDER, HV CABLE	
3	▲.8-735-553-05	CRT (A34JB10X)		11	4-376-557-11	COVER, BACK	
4	1-452-277-00	MAGNET, BMC		12	*4-380-928-01	LABEL, MODEL NUMBER	
5	3-703-003-00	SPACER, DY		13	4-308-870-00	CLIP, LEAD WIRE	
6	▲.1-451-249-31	DEFLECTION YOKE (SY-125B)		14	1-452-032-00	MAGNET, DISK; 10MM ϕ	
7	*A-1330-757-A	C BOARD, COMPLETE		15	1-452-094-00	MAGNET, ROTATABLE DISK; 15MM ϕ	
8	▲.1-426-145-13	COIL, DEGAUSSING		16	X-4309-608-0	PERMALLOY ASSY, CONVERGENCE	

5-2. BEZEL ASSY

●: TA, BV3x12 7-685-648-71

▲: TA, BV4x16 7-685-663-71



No.	Part No.	Description	Remark	No.	Part No.	Description	Remark
51	X-4374-994-1	BEZEL ASSY	52-58	65	4-376-531-11	BUTTON (B), POWER	
52	X-4374-993-1	DOOR ASSY, CONTROL		66	▲4-022-115-01	HOLDER, AC CORD	
53	4-840-002-00	EMBLEM, SONY		67	▲1-534-817-61	CORD, POWER	
54	4-376-532-01	WINDOW (B), TUNING		68	*X-4374-934-1	GUIDE ASSY, LIGHT	
55	4-374-926-11	PUSH BUTTON		69	*4-381-686-01	BRACKET (B), BAR, OPTICAL	
56	4-376-516-21	BUTTON, CONTROL		70	*4-374-987-01	GUIDE, LIGHT	
57	*4-374-962-01	NET, SPEAKER		71	*A-1135-390-A	B BOARD, COMPLETE	
58	4-376-518-11	BUTTON, MULTI		72	▲1-439-311-32	TRANSFORMER ASSY, FLYBACK	
59	1-503-344-21	SPEAKER		73	4-375-751-01	CASE, ANT TERMINAL	
60	*A-1296-189-A	A BOARD, COMPLETE		74	*1-558-539-11	CABLE, P-P	
61	▲1-463-577-11	TUNER, ET(8T-883A)		75	*1-618-984-11	D BOARD	
62	*A-1245-341-A	F BOARD, COMPLETE		76	▲1-563-204-12	SOCKET, ANTENNA (PAL/SECAM)	
64	▲1-554-966-12	SWITCH, PUSH (AC POWER)(1 KEY)					

The components identified by shading and mark ▲ are critical for safety. Replace only with part number specified.

BSECTION 6
ELECTRICAL PARTS LIST

NOTE:

The components identified by shading and mark **A** are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board name.

• Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

CAPACITORS
• MF : μ F, PF : μ P

RESISTORS
• All resistors are in ohms
• F : nonflammable

COILS
• MMH : mH, UH : μ H

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
	*A-1135-390-A	B BOARD, COMPLETE *****		C034	1-101-004-00	CERAMIC 0.01MF	50V
	3-531-576-31	RIVET (DIA. 3), NYLON		C035	1-101-004-00	CERAMIC 0.01MF	50V
	3-701-833-01	HEAD, WASHER, TAPPING SCREW		C301	1-101-004-00	CERAMIC 0.01MF	50V
	3-831-441-XX	SPACER		C302	1-124-903-00	ELECT 1MF	20% 50V
	*4-323-833-00	HEAT SINK, PIN OUT		C303	1-124-896-00	ELECT 33MF	20% 16V
	*4-367-523-00	CASE (MAIN), SHIELD					
	*4-367-524-00	LID, UPPER, SHIELD CASE		C305	1-124-903-00	ELECT 1MF	20% 50V
	*4-367-525-00	LID, REAR, SHIELD CASE		C306	1-124-251-00	ELECT 0.22MF	20% 50V
	*4-376-515-01	HOLDER (D), LED		C307	1-124-904-00	ELECT 2.2MF	20% 50V
	*4-376-517-01	HOLDER (A), LED		C308	1-102-963-00	CERAMIC 33PF	5% 50V
				C309	1-102-111-00	CERAMIC 270PF	10% 50V
		CONNECTOR		C310	1-102-111-00	CERAMIC 270PF	10% 50V
B1	*1-508-767-00	5P PLUG		C311	1-124-903-00	ELECT 1MF	20% 50V
B2	*1-564-038-00	CONNECTOR PLUG, DY (MINI) 6P		C312	1-124-903-00	ELECT 1MF	20% 50V
B3	*1-508-765-00	3P PLUG (M)		C314	1-124-927-11	ELECT 4.7MF	20% 50V
B4	*1-508-786-00	2P PLUG (M)		C315	1-124-907-00	ELECT 10MF	20% 50V
B5	*1-560-126-00	PLUG, CONNECTOR (2.5MM) 6P					
B6	*1-560-123-00	PLUG, CONNECTOR (2.5MM) 3P		C316	1-106-184-00	MYLAR 0.0033MF	10% 50V
B7	*1-560-127-00	PLUG, CONNECTOR (2.5MM) 7P		C318	1-124-903-00	ELECT 1MF	20% 50V
B8	*1-560-126-00	PLUG, CONNECTOR (2.5MM PITCH)		C319	1-108-841-91	MYLAR 0.022MF	10% 50V
B9	*1-560-290-00	PLUG, CONNECTOR (2.5MM PITCH)		C320	1-123-608-00	ELECT 0.22MF	20% 50V
B11	*1-560-123-00	PLUG, CONNECTOR (2.5MM PITCH)		C321	1-108-841-91	MYLAR 0.022MF	10% 50V
B12	*1-560-125-00	PLUG, CONNECTOR (2.5MM PITCH)					
B13	*1-560-126-00	PLUG, CONNECTOR (2.5MM PITCH)		C322	1-102-074-00	CERAMIC 0.001MF	10% 50V
B14	*1-560-123-00	PLUG, CONNECTOR (2.5MM PITCH)		C323	1-123-332-00	ELECT 47MF	20% 16V
B15	*1-560-290-00	PLUG, CONNECTOR (2.5MM PITCH)		C324	1-124-907-00	ELECT 10MF	20% 50V
W1	*1-564-346-00	CONNECTOR, BOARD TO BOARD 18P		C325	1-101-004-00	CERAMIC 0.01MF	50V
				C326	1-101-004-00	CERAMIC 0.01MF	50V
		CAPACITOR		C330	1-124-903-00	ELECT 1MF	20% 50V
C001	1-124-903-00	ELECT 1MF	20% 50V	C331	1-123-332-00	ELECT 47MF	20% 16V
C002	1-124-903-00	ELECT 1MF	20% 50V	C336	1-102-074-00	CERAMIC 0.001MF	10% 50V
C003	1-124-903-00	ELECT 1MF	20% 50V	C337	1-102-865-00	CERAMIC 8PF	0.5PF 50V
C004	1-102-973-00	CERAMIC 100PF	5% 50V	C391	1-102-973-00	CERAMIC 100PF	5% 50V
C005	1-108-849-00	MYLAR 0.1MF	10% 50V				
C006	1-102-959-00	CERAMIC 22PF	5% 50V	C392	1-124-907-00	ELECT 10MF	20% 50V
C007	1-102-959-00	CERAMIC 22PF	5% 50V	C402	1-101-004-00	CERAMIC 0.01MF	50V
C009	1-102-111-00	CERAMIC 270PF	10% 50V	C404	1-108-843-91	ELECT 0.033MF	10% 50V
C010	1-102-518-00	CERAMIC 33PF	5% 50V	C405	1-102-110-00	CERAMIC 220PF	10% 50V
C011	1-102-518-00	CERAMIC 33PF	5% 50V	C406	1-124-896-00	ELECT 33MF	20% 16V
C012	1-101-004-00	CERAMIC 0.01MF	50V				
C013	1-102-973-00	CERAMIC 100PF	5% 50V	C407	1-102-971-00	CERAMIC 82PF	5% 50V
C014	1-101-004-00	CERAMIC 0.01MF	50V	C408	1-123-332-00	ELECT 47MF	20% 16V
C015	1-124-907-00	ELECT 10MF	20% 50V	C409	1-124-903-00	ELECT 1MF	20% 50V
C018	1-101-004-00	CERAMIC 0.01MF	50V	C410	1-124-903-00	ELECT 1MF	20% 50V
C019	1-124-907-00	ELECT 10MF	20% 50V	C411	1-124-903-00	ELECT 1MF	20% 50V
C020	1-124-896-00	ELECT 33MF	20% 16V				
C021	1-101-004-00	CERAMIC 0.01MF	50V	C412	1-124-445-00	ELECT 100MF	20% 16V
C022	1-101-004-00	CERAMIC 0.01MF	50V	C413	1-124-907-00	ELECT 10MF	20% 50V
C024	1-124-907-00	ELECT 10MF	20% 50V	C414	1-124-445-00	ELECT 100MF	20% 16V
C029	1-102-074-00	CERAMIC 0.001MF	10% 50V	C415	1-124-646-00	ELECT 22MF	20% 16V
C030	1-101-004-00	CERAMIC 0.01MF	50V	C416	1-124-481-11	ELECT 22MF	20% 25V
C031	1-101-004-00	CERAMIC 0.01MF	50V				
C032	1-102-110-00	CERAMIC 220PF	10% 50V	C417	1-124-907-00	ELECT 10MF	20% 50V
				C418	1-124-475-11	ELECT 470MF	20% 16V
				C419	1-124-903-00	ELECT 1MF	20% 50V
				C420	1-124-903-00	ELECT 1MF	20% 50V
				C421	1-124-445-00	ELECT 100MF	20% 16V
				C422	1-124-903-00	ELECT 1MF	20% 50V
				C423	1-124-907-00	ELECT 10MF	20% 50V
				C424	1-102-121-00	CERAMIC 0.0022MF	10% 50V

Ref.No.	Part No.	Description			Remark	Ref.No.	Part No.	Description			Remark
C425	1-124-556-11	ELECT	2200MF	20%	16V	C857	1-108-425-00	MYLAR	0.022MF	10%	200V
C426	1-124-907-00	ELECT	10MF	20%	50V	C858	1-101-004-00	CERAMIC	0.01MF		50V
C427	1-124-907-00	ELECT	10MF	20%	50V	C859	1-124-445-00	ELECT	100MF	20%	16V
C428	1-124-907-00	ELECT	10MF	20%	50V	C860	1-102-228-00	CERAMIC	470PF	10%	500V
C429	1-124-903-00	ELECT	1MF	20%	50V	C861	1-101-880-00	CERAMIC	47PF	5%	50V
C430	1-124-445-00	ELECT	100MF	20%	16V	C862	1-101-003-00	CERAMIC	0.0047MF		50V
C431	1-124-902-00	ELECT	0.47MF	20%	50V	C863	1-124-901-00	ELECT	1000MF	20%	35V
C432	1-124-902-00	ELECT	0.47MF	20%	50V						
C433	1-124-902-00	ELECT	0.47MF	20%	50V			<u>FILTER</u>			
C434	1-124-903-00	ELECT	1MF	20%	50V						
C439	1-124-445-00	ELECT	100MF	20%	16V	CF001	1-567-192-11	OSCILLATOR, CERAMIC			
C440	1-102-114-00	CERAMIC	470PF	10%	50V			<u>TRIMMER</u>			
C441	1-102-114-00	CERAMIC	470PF	10%	50V						
C525	1-123-321-00	ELECT	220MF	20%	16V	CV301	1-141-181-11	CAP, TRIMMER			
C529	1-102-110-00	CERAMIC	220PF	10%	50V			<u>DIODE</u>			
C531	1-102-965-00	CERAMIC	39PF	5%	50V						
C551	1-102-244-00	CERAMIC	220PF	10%	500V	D002	8-719-911-19	DIODE 1SS119			
C552	1-102-244-00	CERAMIC	220PF	10%	500V	D004	8-719-901-96	DIODE SLP161B			
C553	1-124-122-11	ELECT	100MF	20%	50V	D005	8-719-800-94	DIODE TLUR144			
C554	1-106-196-00	MYLAR	0.01MF	10%	100V	D006	8-719-911-19	DIODE 1SS119			
						D007	8-719-911-19	DIODE 1SS119			
C555	1-124-117-00	ELECT	680MF	10%	25V						
C556	1-108-622-91	MYLAR	0.0047MF	10%	100V	D008	8-719-911-19	DIODE 1SS119			
C557	1-161-271-00	CERAMIC	100PF	5%	50V	D009	8-719-911-19	DIODE 1SS119			
C801	1-123-024-00	ELECT	33MF		160V	D010	8-719-911-19	DIODE 1SS119			
C802	1-102-114-00	CERAMIC	470PF	10%		D011	8-719-911-19	DIODE 1SS119			
						D012	8-719-110-72	DIODE RD30ES-B2			
C803	1-106-367-00	MYLAR	0.01MF	10%	200V						
C804	1-102-038-00	CERAMIC	0.001MF		500V	D016	8-719-911-19	DIODE 1SS119			
C805	1-102-244-00	CERAMIC	220PF	10%	500V	D017	8-719-911-19	DIODE 1SS119			
C806	1-102-212-00	CERAMIC	820PF	10%	500V	D018	8-719-911-19	DIODE 1SS119			
C807	1-136-236-11	FILM	0.47MF	5%	400V	D019	8-719-109-89	DIODE RD5.6ES-B2			
						D020	8-719-911-19	DIODE 1SS119			
C808	1-106-367-00	MYLAR	0.01MF	10%	200V						
C809	1-162-116-00	CERAMIC	680PF	10%	2KV	D022	8-719-911-19	DIODE 1SS119			
C810	1-106-200-00	MYLAR	0.015MF	10%	100V	D023	8-719-911-19	DIODE 1SS119			
C811	1-162-116-00	CERAMIC	680PF	10%	2KV	D024	8-719-911-19	DIODE 1SS119			
C812	△ 1-136-092-11	FILM	0.0072MF	3%	2KV	D025	8-719-109-71	DIODE RD3.9ES-B1			
						D041	8-719-911-19	DIODE 1SS119			
C813	1-101-880-00	CERAMIC	47PF	5%	50V						
C814	1-102-112-00	CERAMIC	330PF	10%	50V	D301	8-719-911-19	DIODE 1SS119			
C815	1-124-645-11	ELECT	10MF	20%	16V	D302	8-719-911-19	DIODE 1SS119			
C817	△ 1-162-115-51	CERAMIC	330PF	10%	2KV	D303	8-719-911-19	DIODE 1SS119			
C818	1-101-004-00	CERAMIC	0.01MF		50V	D306	8-719-911-19	DIODE 1SS119			
						D307	8-719-911-19	DIODE 1SS119			
C821	1-108-630-91	MYLAR	0.022MF	10%	100V						
C822	1-102-228-00	CERAMIC	470PF	10%	500V	D308	8-719-911-19	DIODE 1SS119			
C823	1-102-002-00	CERAMIC	680PF	10%	500V	D391	8-719-911-19	DIODE 1SS119			
C824	1-124-002-11	ELECT	1MF	20%	50V	D402	8-719-911-19	DIODE 1SS119			
C825	1-124-903-00	ELECT	1MF	20%	50V	D403	8-719-911-19	DIODE 1SS119			
						D405	8-719-110-19	DIODE RD11ES-B			
C826	1-106-200-00	MYLAR	0.015MF	10%	100V						
C827	1-136-060-00	FILM	0.047MF	5%	400V	D406	8-719-108-12	DIODE RD9.1E-W			
C851	1-123-948-00	ELECT	22MF	20%	250V	D407	8-719-108-12	DIODE RD9.1E-W			
C852	1-162-114-00	CERAMIC	0.0047MF		2KV	D408	8-719-110-38	DIODE RD15ES-B			
C853	1-102-038-00	CERAMIC	0.001MF		500V	D501	8-719-911-19	DIODE 1SS119			
						D504	8-719-911-19	DIODE 1SS119			
C854	1-124-120-11	ELECT	220MF	20%	25V						
C855	1-124-907-00	ELECT	10MF	20%	50V	D551	8-719-200-02	DIODE 10E2			
C856	1-102-038-00	CERAMIC	0.001MF		500V	D821	8-719-200-02	DIODE 10E2			
						D822	8-719-200-02	DIODE 10E2			

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

B

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
D823	8-719-200-02	DIODE 10E2		<u>TRANSISTOR</u>			
D824	8-719-931-05	DIODE EQ801-05		Q001	8-729-178-54	TRANSISTOR 2SC2785	
D851	8-719-901-93	DIODE V19E		Q002	8-729-900-89	TRANSISTOR DTC144ES	
D852	8-719-300-65	DIODE ES1F		Q003	8-729-900-63	TRANSISTOR DTA124ES	
D853	8-719-901-93	DIODE V19E		Q004	8-729-603-50	TRANSISTOR 2SC403SP	
				Q005	8-729-178-54	TRANSISTOR 2SC2785	
D854	8-719-200-02	DIODE 10E2		Q006	8-729-178-54	TRANSISTOR 2SC2785	
D855	8-719-901-93	DIODE V19E		Q007	8-729-900-36	TRANSISTOR DTC124ES	
D856	8-719-110-35	DIODE RD13ES-B1		Q008	8-729-900-63	TRANSISTOR DTA124ES	
				Q009	8-729-900-63	TRANSISTOR DTA124ES	
				Q010	8-729-178-54	TRANSISTOR 2SC2785	
				Q011	8-729-178-54	TRANSISTOR 2SC2785	
				Q012	8-729-117-54	TRANSISTOR 2SA1175	
				Q013	8-729-900-89	TRANSISTOR DTC144ES	
				Q301	8-729-178-54	TRANSISTOR 2SC2785	
				Q302	8-729-117-54	TRANSISTOR 2SA1175	
				Q303	8-729-117-54	TRANSISTOR 2SA1175	
				Q304	8-729-178-54	TRANSISTOR 2SC2785	
				Q305	8-729-178-54	TRANSISTOR 2SC2785	
				Q306	8-729-117-54	TRANSISTOR 2SA1175	
				Q307	8-729-900-83	TRANSISTOR DTC124XS	
				Q309	8-729-178-54	TRANSISTOR 2SC2785	
				Q310	8-729-178-54	TRANSISTOR 2SC2785	
				Q311	8-729-115-30	TRANSISTOR 2SK105A-30	
				Q402	8-729-117-54	TRANSISTOR 2SA1175	
				Q404	8-729-178-54	TRANSISTOR 2SC2785	
				Q405	8-729-178-54	TRANSISTOR 2SC2785	
				Q406	8-729-178-54	TRANSISTOR 2SC2785	
				Q409	8-729-117-54	TRANSISTOR 2SA1175	
				Q410	8-729-178-54	TRANSISTOR 2SC2785	
				Q411	8-729-178-54	TRANSISTOR 2SC2785	
				Q412	8-729-178-54	TRANSISTOR 2SC2785	
				Q413	8-729-178-54	TRANSISTOR 2SC2785	
				Q414	8-729-178-54	TRANSISTOR 2SC2785	
				Q415	8-729-900-36	TRANSISTOR DTC124ES	
				Q416	8-729-178-54	TRANSISTOR 2SC2785	
				Q417	8-729-178-54	TRANSISTOR 2SC2785	
				Q418	8-729-178-54	TRANSISTOR 2SC2785	
				Q419	8-729-178-54	TRANSISTOR 2SC2785	
				Q420	8-729-900-89	TRANSISTOR DTC144ES	
				Q801	8-729-168-82	TRANSISTOR 2SC2688	
				Q802	8-729-206-04	TRANSISTOR 2SD1554	
				Q803	8-729-178-54	TRANSISTOR 2SC2785	
				Q804	8-729-178-54	TRANSISTOR 2SC2785	
				Q821	8-729-378-91	TRANSISTOR 2SD789	
				Q851	8-729-313-42	TRANSISTOR 2SD1134	
				<u>RESISTOR</u>			
				R004	1-247-875-00	CARBON 68K 5% 1/6W	
				R005	1-247-859-00	CARBON 15K 5% 1/6W	
				R007	1-249-432-11	CARBON 18K 5% 1/6W	
				R008	1-249-429-11	CARBON 10K 5% 1/6W	
<u>DELAY LINE</u>							
DL301	1-415-122-31	DELAY LINE, 1H (PAL)					
<u>IC</u>							
IC001	8-759-602-81	IC M50436-511SP					
IC002	8-759-603-41	IC M58655P					
IC003	8-741-139-80	IC BX1398					
IC004	8-759-157-40	IC UPC574J					
IC301	8-752-030-86	IC CXA1001AP					
IC401	8-752-006-10	IC CX20061					
IC402	8-752-006-10	IC CX20061					
IC403	8-752-006-10	IC CX20061					
IC404	8-752-010-00	IC CX20100					
IC551	8-759-801-98	IC LA7830					
<u>JACK</u>							
J401	1-561-534-00	SOCKET 21P					
<u>COIL</u>							
JW7	1-408-409-00	MICRO INDUCTOR 10UH					
L001	1-408-411-00	MICRO INDUCTOR 15UH					
L002	1-408-411-00	MICRO INDUCTOR 15UH					
L004	1-408-415-00	MICRO INDUCTOR 33UH					
L005	1-408-409-00	MICRO INDUCTOR 10UH					
L006	1-408-403-00	MICRO INDUCTOR 3.3UH					
L007	1-410-316-11	MICRO INDUCTOR 1UH					
L302	1-408-244-00	MICRO INDUCTOR 18MMH					
L303	1-408-415-00	MICRO INDUCTOR 33UH					
L304	1-408-409-00	MICRO INDUCTOR 10UH					
L305	1-408-300-00	MICRO INDUCTOR 6.8UH					
L391	1-408-245-00	MICRO INDUCTOR 22MMH					
L401	1-408-409-00	MICRO INDUCTOR 10UH					
L404	1-408-415-00	MICRO INDUCTOR 33UH					
L405	1-408-417-00	MICRO INDUCTOR 47UH					
L551	1-408-698-00	MICRO INDUCTOR 8.2UH					
L801	1-407-556-00	CHOKE COIL					
L802	1-407-364-00	COIL, SPOOK CHOKE 3.3UH					
L803	1-407-365-00	COIL, CHOKE					
L804	1-421-013-00	COIL, (HORIZONTAL CHOKE) 25UH					
L805	1-459-496-00	COIL, FERRITE (HLC)					
L806	1-459-315-00	COIL, VAR, FERRITE (HWC)					
L821	1-459-105-21	COIL(WITH CORE)					
L822	1-407-494-00	MICRO INDUCTOR 1.5MMH					
L851	1-408-240-00	MICRO INDUCTOR 6.8MMH					

Ref.No.	Part No.	Description				Remark	Ref.No.	Part No.	Description				Remark
R009	1-247-725-11	CARBON	10K	5%	1/4W		R180	1-249-419-11	CARBON	1.5K	5%	1/6W	
R010	1-249-433-11	CARBON	22K	5%	1/6W		R301	1-247-823-00	CARBON	470	5%	1/6W	
R011	1-249-433-11	CARBON	22K	5%	1/6W		R302	1-249-433-11	CARBON	22K	5%	1/6W	
R012	1-249-433-11	CARBON	22K	5%	1/6W		R304	1-249-497-11	CARBON	33K	5%	1/4W	
R013	1-249-433-11	CARBON	22K	5%	1/6W		R305	1-247-887-00	CARBON	220K	5%	1/6W	
R014	1-215-900-11	METAL OXIDE	22K	5%	2W	F	R306	1-249-419-11	CARBON	1.5K	5%	1/6W	
R016	1-247-821-00	CARBON	390	5%	1/6W		R307	1-247-725-11	CARBON	10K	5%	1/4W	
R017	1-247-821-00	CARBON	390	5%	1/6W		R308	1-249-429-11	CARBON	10K	5%	1/6W	
R019	1-247-823-00	CARBON	470	5%	1/6W		R309	1-247-851-00	CARBON	6.8K	5%	1/6W	
R020	1-247-708-11	CARBON	470	5%	1/4W		R310	1-246-535-00	CARBON	390K	5%	1/4W	
R021	1-247-823-00	CARBON	470	5%	1/6W		R311	1-247-903-00	CARBON	1M	5%	1/6W	
R022	1-247-823-00	CARBON	470	5%	1/6W		R312	1-249-435-11	CARBON	33K	5%	1/6W	
R023	1-247-823-00	CARBON	470	5%	1/6W		R313	1-249-432-11	CARBON	18K	5%	1/6W	
R024	1-247-823-00	CARBON	470	5%	1/6W		R314	1-246-541-00	CARBON	680K	5%	1/4W	
R025	1-247-823-00	CARBON	470	5%	1/6W		R315	1-247-883-00	CARBON	150K	5%	1/6W	
R026	1-247-823-00	CARBON	470	5%	1/6W		R316	1-249-441-11	CARBON	100K	5%	1/6W	
R027	1-247-823-00	CARBON	470	5%	1/6W		R317	1-249-441-11	CARBON	100K	5%	1/6W	
R028	1-247-873-00	CARBON	56K	5%	1/6W		R318	1-249-441-11	CARBON	100K	5%	1/6W	
R029	1-249-429-11	CARBON	10K	5%	1/6W		R319	1-249-441-11	CARBON	100K	5%	1/6W	
R030	1-249-429-11	CARBON	10K	5%	1/6W		R320	1-247-725-11	CARBON	10K	5%	1/4W	
R031	1-247-823-00	CARBON	470	5%	1/6W		R321	1-249-467-11	CARBON	68K	5%	1/4W	
R032	1-247-823-00	CARBON	470	5%	1/6W		R322	1-249-415-11	CARBON	680	5%	1/6W	
R034	1-247-823-00	CARBON	470	5%	1/6W		R323	1-249-422-11	CARBON	2.7K	5%	1/6W	
R036	1-249-429-11	CARBON	10K	5%	1/6W		R324	1-247-859-00	CARBON	15K	5%	1/6W	
R037	1-249-429-11	CARBON	10K	5%	1/6W		R325	1-247-851-00	CARBON	6.8K	5%	1/6W	
R038	1-249-433-11	CARBON	22K	5%	1/6W		R326	1-247-849-00	CARBON	5.6K	5%	1/6W	
R039	1-247-163-00	CARBON	22K	5%	1/4W		R327	1-247-145-00	CARBON	3.9K	5%	1/4W	
R041	1-247-704-11	CARBON	220	5%	1/4W		R328	1-247-869-00	CARBON	39K	5%	1/6W	
R042	1-249-429-11	CARBON	10K	5%	1/6W		R329	1-247-883-00	CARBON	150K	5%	1/6W	
R043	1-247-725-11	CARBON	10K	5%	1/4W		R331	1-247-859-00	CARBON	15K	5%	1/6W	
R044	1-247-823-00	CARBON	470	5%	1/6W		R332	1-249-433-11	CARBON	22K	5%	1/6W	
R045	1-247-823-00	CARBON	470	5%	1/6W		R333	1-247-821-00	CARBON	390	5%	1/6W	
R046	1-247-708-11	CARBON	470	5%	1/4W		R334	1-249-417-11	CARBON	1K	5%	1/6W	
R047	1-247-823-00	CARBON	470	5%	1/6W		R335	1-249-433-11	CARBON	22K	5%	1/6W	
R048	1-247-708-11	CARBON	470	5%	1/4W		R336	1-249-435-11	CARBON	33K	5%	1/6W	
R050	1-249-497-11	CARBON	33K	5%	1/4W		R337	1-249-433-11	CARBON	22K	5%	1/6W	
R051	1-247-708-11	CARBON	470	5%	1/4W		R338	1-249-437-11	CARBON	47K	5%	1/6W	
R052	1-247-823-00	CARBON	470	5%	1/6W		R339	1-247-823-00	CARBON	470	5%	1/6W	
R053	1-249-429-11	CARBON	10K	5%	1/6W		R340	1-247-869-00	CARBON	39K	5%	1/6W	
R054	1-247-873-00	CARBON	56K	5%	1/6W		R341	1-247-869-00	CARBON	39K	5%	1/6W	
R055	1-247-823-00	CARBON	470	5%	1/6W		R342	1-247-859-00	CARBON	15K	5%	1/6W	
R056	1-247-708-11	CARBON	470	5%	1/4W		R343	1-247-853-00	CARBON	8.2K	5%	1/6W	
R059	1-249-417-11	CARBON	1K	5%	1/6W		R344	1-247-875-00	CARBON	68K	5%	1/6W	
R060	1-249-429-11	CARBON	10K	5%	1/6W		R345	1-247-875-00	CARBON	68K	5%	1/6W	
R061	1-249-441-11	CARBON	100K	5%	1/6W		R346	1-249-429-11	CARBON	10K	5%	1/6W	
R062	1-247-875-00	CARBON	68K	5%	1/6W		R347	1-249-421-11	CARBON	2.2K	5%	1/6W	
R063	1-249-434-11	CARBON	27K	5%	1/6W		R348	1-249-437-11	CARBON	47K	5%	1/6W	
R064	1-249-417-11	CARBON	1K	5%	1/6W		R350	1-249-433-11	CARBON	22K	5%	1/6W	
R065	1-249-433-11	CARBON	22K	5%	1/6W		R353	1-249-417-11	CARBON	1K	5%	1/6W	
R066	1-249-425-11	CARBON	4.7K	5%	1/6W		R354	1-247-819-00	CARBON	330	5%	1/6W	
R070	1-249-429-11	CARBON	10K	5%	1/6W		R355	1-247-859-00	CARBON	15K	5%	1/6W	
R071	1-426-527-00	CARBON	180K	5%	1/4W		R362	1-249-440-11	CARBON	82K	5%	1/6W	
R178	1-249-417-11	CARBON	1K	5%	1/6W		R366	1-249-435-11	CARBON	33K	5%	1/6W	
R179	1-249-417-11	CARBON	1K	5%	1/6W								

KV-1442ECPS

RM-651

B

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R370	1-247-851-00	CARBON	6.8K 5% 1/6W	R457	1-249-417-11	CARBON	1K 5% 1/6W
R371	1-247-891-00	CARBON	330K 5% 1/6W	R458	1-249-417-11	CARBON	1K 5% 1/6W
R391	1-249-423-11	CARBON	3.3K 5% 1/6W	R459	1-249-417-11	CARBON	1K 5% 1/6W
R392	1-247-849-00	CARBON	5.6K 5% 1/6W	R460	1-247-704-11	CARBON	220 5% 1/4W
R401	1-249-417-11	CARBON	1K 5% 1/6W	R461	1-247-704-11	CARBON	220 5% 1/4W
R402	1-249-429-11	CARBON	10K 5% 1/6W	R462	1-247-704-11	CARBON	220 5% 1/4W
R403	1-249-433-11	CARBON	22K 5% 1/6W	R463	1-247-804-00	CARBON	75 5% 1/6W
R404	1-247-859-00	CARBON	15K 5% 1/6W	R464	1-247-804-00	CARBON	75 5% 1/6W
R406	1-249-469-11	CARBON	100K 5% 1/4W	R465	1-247-804-00	CARBON	75 5% 1/6W
R408	1-247-903-00	CARBON	1M 5% 1/6W	R466	1-247-804-00	CARBON	75 5% 1/6W
R410	1-247-708-11	CARBON	470 5% 1/4W	R467	1-247-104-00	CARBON	75 5% 1/4W
R411	1-216-430-11	METAL OXIDE	390 5% 1W F	R468	1-247-813-00	CARBON	180 5% 1/6W
R412	1-249-421-11	CARBON	2.2K 5% 1/6W	R469	1-247-813-00	CARBON	180 5% 1/6W
R413	1-247-853-00	CARBON	8.2K 5% 1/6W	R470	1-247-713-11	CARBON	1K 5% 1/4W
R414	1-247-859-00	CARBON	15K 5% 1/6W	R471	1-249-440-11	CARBON	82K 5% 1/6W
R415	1-249-417-11	CARBON	1K 5% 1/6W	R472	1-249-429-11	CARBON	10K 5% 1/6W
R416	1-249-417-11	CARBON	1K 5% 1/6W	R473	1-249-425-11	CARBON	4.7K 5% 1/6W
R419	1-249-419-11	CARBON	1.5K 5% 1/6W	R474	1-247-704-11	CARBON	220 5% 1/4W
R420	1-247-815-00	CARBON	220 5% 1/6W	R478	1-247-704-11	CARBON	220 5% 1/4W
R421	1-249-421-11	CARBON	2.2K 5% 1/6W	R479	1-247-700-11	CARBON	100 5% 1/4W
R422	1-247-859-00	CARBON	15K 5% 1/6W	R480	1-247-700-11	CARBON	100 5% 1/4W
R423	1-247-725-11	CARBON	10K 5% 1/4W	R481	1-247-700-11	CARBON	100 5% 1/4W
R424	1-249-437-11	CARBON	47K 5% 1/6W	R482	1-247-700-11	CARBON	100 5% 1/4W
R425	1-247-889-00	CARBON	270K 5% 1/6W	R483	1-249-405-11	CARBON	100 5% 1/6W
R426	1-249-469-11	CARBON	100K 5% 1/4W	R484	1-249-405-11	CARBON	100 5% 1/6W
R427	1-249-441-11	CARBON	100K 5% 1/6W	R485	1-247-718-11	CARBON	2.7K 5% 1/4W
R429	1-247-708-11	CARBON	470 5% 1/4W	R486	1-249-469-11	CARBON	100K 5% 1/4W
R430	1-247-823-00	CARBON	470 5% 1/6W	R487	1-247-875-00	CARBON	68K 5% 1/6W
R431	1-247-875-00	CARBON	68K 5% 1/6W	R488	1-246-541-00	CARBON	680K 5% 1/4W
R432	1-249-425-11	CARBON	4.7K 5% 1/6W	R489	1-247-885-00	CARBON	180K 5% 1/6W
R433	1-249-419-11	CARBON	1.5K 5% 1/6W	R491	1-249-423-11	CARBON	3.3K 5% 1/6W
R434	1-247-851-00	CARBON	6.8K 5% 1/6W	R492	1-249-423-11	CARBON	3.3K 5% 1/6W
R435	1-249-425-11	CARBON	4.7K 5% 1/6W	R493	1-249-423-11	CARBON	3.3K 5% 1/6W
R436	1-247-717-11	CARBON	2.2K 5% 1/4W	R494	1-249-429-11	CARBON	10K 5% 1/6W
R437	1-247-851-00	CARBON	6.8K 5% 1/6W	R497	1-247-804-00	CARBON	75 5% 1/6W
R438	1-247-725-11	CARBON	10K 5% 1/4W	R498	1-247-804-00	CARBON	75 5% 1/6W
R439	1-249-405-11	CARBON	100 5% 1/6W	R499	1-247-104-00	CARBON	75 5% 1/4W
R440	1-249-425-11	CARBON	4.7K 5% 1/6W	R503	1-249-427-11	CARBON	6.8K 5% 1/6W F
R441	1-249-429-11	CARBON	10K 5% 1/6W	R512	1-216-440-00	METAL OXIDE	18K 5% 1W F
R442	1-249-429-11	CARBON	10K 5% 1/6W	R513	1-249-423-11	CARBON	3.3K 5% 1/6W
R443	1-247-833-00	CARBON	1.2K 5% 1/6W	R530	1-215-373-31	METAL	10 1% 1/6W
R444	1-247-851-00	CARBON	6.8K 5% 1/6W	R532	1-247-711-11	CARBON	680 5% 1/4W
R445	1-249-423-11	CARBON	3.3K 5% 1/6W	R536	1-249-437-11	CARBON	47K 5% 1/6W
R446	1-249-429-11	CARBON	10K 5% 1/6W	R537	1-249-435-11	CARBON	33K 5% 1/6W
R447	1-249-421-11	CARBON	2.2K 5% 1/6W	R539	1-249-429-11	CARBON	10K 5% 1/6W
R448	1-249-417-11	CARBON	1K 5% 1/6W	R551	1-215-373-31	METAL	10 1% 1/6W
R449	1-247-708-11	CARBON	470 5% 1/4W	R552	1-247-226-00	CARBON	270 5% 1/2W
R450	1-249-417-11	CARBON	1K 5% 1/6W	R553	1-216-373-11	METAL OXIDE	2.2 5% 2W F
R451	1-249-469-11	CARBON	100K 5% 1/4W	R554	1-215-867-00	METAL OXIDE	470 5% 1W F
R453	1-249-433-11	CARBON	22K 5% 1/6W	R801	1-247-819-00	CARBON	330 5% 1/6W
R454	1-249-460-11	CARBON	15K 5% 1/4W	R802	1-249-425-11	CARBON	4.7K 5% 1/6W
R455	1-249-460-11	CARBON	15K 5% 1/4W	R803	1-205-642-00	CEMENTED	3.3K 10% 5W
R456	1-249-429-11	CARBON	10K 5% 1/6W	R804	1-247-721-11	CARBON	4.7K 5% 1/4W F

B

D

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
R805	1-249-421-11	CARBON	2.2K 5% 1/6W	<u>SWITCH</u>			
R806	1-249-437-11	CARBON	47K 5% 1/6W	S002	1-554-804-11	SWITCH, PUSH (1 KEY)	
R807	1-215-867-00	METAL OXIDE	470 5% 1W F	S003	1-554-804-11	SWITCH, PUSH (1 KEY)	
R808	1-215-883-11	METAL OXIDE	33 5% 2W F	S004	1-554-804-11	SWITCH, PUSH (1 KEY)	
R809	1-247-887-00	CARBON	220K 5% 1/6W	S005	1-554-804-11	SWITCH, PUSH (1 KEY)	
R811	1-249-435-11	CARBON	33K 5% 1/6W	S006	1-554-804-11	SWITCH, PUSH (1 KEY)	
R812	1-247-833-00	CARBON	1.2K 5% 1/6W	S007	1-554-804-11	SWITCH, PUSH (1 KEY)	
R813	1-249-425-11	CARBON	4.7K 5% 1/6W	S008	1-554-804-11	SWITCH, PUSH (1 KEY)	
R814	1-249-429-11	CARBON	10K 5% 1/6W F	S009	1-554-804-11	SWITCH, PUSH (1 KEY)	
R815	1-247-823-00	CARBON	470 5% 1/6W	S010	1-554-804-11	SWITCH, PUSH (1 KEY)	
R816	1-249-427-11	CARBON	6.8K 5% 1/6W F	S011	1-554-804-11	SWITCH, PUSH (1 KEY)	
R817	1-247-883-00	CARBON	150K 5% 1/6W	S301	1-570-704-11	SWITCH, ROTARY	
R819	1-216-429-00	METAL OXIDE	270 5% 1W F	<u>BLOCK</u>			
R820	1-249-429-11	CARBON	10K 5% 1/6W	SCM301	1-464-545-31	BLOCK (SCB-3)	
R821	1-202-830-00	SOLID	10K 10% 1/2W	<u>SPARK GAP</u>			
R822	1-202-814-91	SOLID	33K 10% 1/2W	SG801	1-519-063-XX	DISCHARGING GAP	
R823	1-249-433-11	CARBON	22K 5% 1/6W	<u>TRANSFORMER</u>			
R824	1-216-427-00	METAL OXIDE	120 5% 1W F	T301	1-404-524-11	DAT	
R825	1-249-402-11	CARBON	56 5% 1/6W F	T801	1-437-078-00	TRANSFORMER, HORIZONTAL DRIVE	
R826	1-249-425-11	CARBON	4.7K 5% 1/6W	T802	1-421-268-00	H.PCT	
R827	1-247-845-00	CARBON	3.9K 5% 1/6W	T851	1-439-311-32	TRANSFORMER ASSY, FLYBACK	
R828	1-249-435-11	CARBON	33K 5% 1/6W	<u>CRYSTAL</u>			
R829	1-249-421-11	CARBON	2.2K 5% 1/6W F	X301	1-567-504-11	OSCILLATOR, CRYSTAL	
R830	1-215-857-11	METAL OXIDE	10 5% 1W F	<u>MODULE</u>			
R832	1-215-882-00	METAL OXIDE	22 5% 2W F	YCM301	1-235-833-11	YC MODULE	
R851	1-249-382-11	CARBON	1.2 5% 1/6W F	*****			
R852	1-217-505-11	FUSIBLE	1K 5% 1W F	*1-618-984-11	D BOARD		
R853	1-249-377-11	CARBON	0.47 5% 1/6W F		*****		
R854	1-249-377-11	CARBON	0.47 5% 1/6W F	<u>CAPACITOR</u>			
R855	1-202-830-00	SOLID	10K 10% 1/2W	C501	1-108-845-00	MYLAR	0.047MF 10% 50V
R856	1-247-151-00	CARBON	6.8K 5% 1/4W	C502	1-108-825-91	MYLAR	0.001MF 10% 50V
R857	1-246-527-00	CARBON	180K 5% 1/4W	C503	1-124-903-00	ELECT	1MF 20% 50V
R858	1-247-849-00	CARBON	5.6K 5% 1/6W	C504	1-106-176-00	MYLAR	0.0015MF 10% 50V
R859	1-215-866-11	METAL OXIDE	330 5% 1W F	C506	1-108-837-00	MYLAR	0.01MF 10% 50V
R860	1-247-883-00	CARBON	150K 5% 1/6W	C507	1-108-841-91	MYLAR	0.022MF 10% 50V
R4001	1-247-815-00	CARBON	220 5% 1/6W	C508	1-124-903-00	ELECT	1MF 20% 50V
R4002	1-249-415-11	CARBON	680 5% 1/6W	C509	1-124-903-00	ELECT	1MF 20% 50V
R4003	1-249-421-11	CARBON	2.2K 5% 1/6W	C510	1-108-841-91	MYLAR	0.022MF 10% 50V
R4004	1-249-417-11	CARBON	1K 5% 1/6W	C511	1-106-180-00	MYLAR	0.0022MF 5% 100V
R4005	1-249-417-11	CARBON	1K 5% 1/6W	C512	1-129-794-00	FILM	0.0033MF 2% 100V
R4006	1-249-417-11	CARBON	1K 5% 1/6W	C513	1-124-903-00	ELECT	1MF 20% 50V
<u>VARIABLE RESISTOR</u>				C514	1-123-321-00	ELECT	220MF 20% 16V
RV302	1-230-626-41	RES, ADJ, CARBON	470	C515	1-106-212-00	MYLAR	0.047MF 5% 100V
RV303	1-230-630-11	RES, ADJ, CARBON	10K	C516	1-124-445-00	ELECT	100MF 20% 16V
RV304	1-230-631-11	RES, ADJ, CARBON	22K				
RV305	1-230-916-11	RES, VAR, CARBON	10K				
RV401	1-230-631-11	RES, ADJ, CARBON	22K				
RV402	1-230-631-11	RES, ADJ, CARBON	22K				
RV403	1-230-271-00	RES, ADJ, CARBON	4.7K				
RV505	1-230-915-11	RES, VAR, CARBON	10K				
RV551	1-224-250-XX	RES, ADJ, METAL GLAZE	2.2K				
RV801	1-223-102-00	RES, ADJ, WIREWOUND	120				

The components identified by shading and mark Δ are critical for safety. Replace only with part number specified.

D

F

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C517	1-124-896-00	ELECT 33MF	20% 16V	C602	<u>A</u> .1-161-964-61	CERAMIC 0.0047MF	250V
C518	1-131-371-00	TANTALUM 10MF	10% 16V	C603	<u>A</u> .1-161-964-61	CERAMIC 0.0047MF	250V
C519	1-136-173-00	FILM 0.47MF	5% 50V	C604	1-161-964-00	CERAMIC 0.0047MF	250V
C521	1-124-903-00	ELECT 1MF	20% 50V	C605	1-125-318-00	ELECT(BLOCK) 220MF	20% 400V
C522	1-108-837-00	MYLAR 0.01MF	10% 50V	C606	1-136-065-00	FILM 0.0027MF	3% 2KV
C523	1-124-903-00	ELECT 1MF	20% 50V	C607	1-102-030-00	CERAMIC 330PF	10% 500V
C524	1-108-593-00	MYLAR 0.039MF	10% 50V	C608	1-123-024-00	ELECT 33MF	160V
C527	1-102-973-00	CERAMIC 100PF	5% 50V	C609	1-124-479-11	ELECT 330MF	20% 25V
C530	1-101-003-00	CERAMIC 0.0047MF	50V	C610	1-102-030-00	CERAMIC 330PF	10% 500V
<u>DIODE</u>				C611	1-124-445-00	ELECT 100MF	20% 16V
D502	8-719-911-19	DIODE 1SS119		C612	1-108-688-91	MYLAR 0.0047MF	10% 200V
<u>CONNECTOR</u>				C613	1-102-030-00	CERAMIC 330PF	10% 500V
F1	*1-562-370-21	CONNECTOR, BOARD TO BOARD 18P		C614	1-124-929-11	ELECT 22MF	20% 100V
<u>IC</u>				C615	1-161-973-00	CERAMIC 220PF	10% 400V
IC501	8-759-100-60	IC UPC1377C		C616	<u>A</u> .1-162-578-51	CERAMIC 0.0047MF	20% 400V
<u>RESISTOR</u>				C617	1-124-927-11	ELECT 4.7MF	20% 100V
R501	1-247-819-00	CARBON 330 5%	1/6W	C617B	1-101-003-00	CERAMIC 0.0047MF	50V
R502	1-247-705-11	CARBON 270 5%	1/4W	C618	1-101-005-00	CERAMIC 0.022MF	50V
R504	1-249-440-11	CARBON 82K 5%	1/6W	C619	1-124-907-00	ELECT 10MF	20% 50V
R505	1-249-423-11	CARBON 3.3K 5%	1/6W	C620	1-108-849-00	MYLAR 0.1MF	10% 50V
R506	1-247-868-00	CARBON 36K 5%	1/6W	C621	1-106-180-00	MYLAR 0.0022MF	5% 100V
R507	1-247-857-00	CARBON 12K 5%	1/6W	C622	1-124-904-00	ELECT 2.2MF	20% 50V
R511	1-249-440-11	CARBON 82K 5%	1/6W	C623	1-102-110-00	CERAMIC 220PF	10% 50V
R514	1-215-460-00	METAL 43K 1%	1/6W	C624	1-123-617-00	ELECT 10MF	20% 16V
R515	1-249-425-11	CARBON 4.7K 5%	1/6W	C625	1-161-973-00	CERAMIC 220PF	10% 400V
R517	1-247-859-00	CARBON 15K 5%	1/6W	C626	1-102-038-00	CERAMIC 0.001MF	500V
R519	1-249-425-11	CARBON 4.7K 5%	1/6W	C627	1-108-837-00	MYLAR 0.01MF	10% 50V
R522	1-215-463-00	METAL 56K 1%	1/6W	C630	1-102-820-00	CERAMIC 330PF	5% 50V
R524	1-215-475-00	METAL 180K 1%	1/6W	C631	1-102-074-00	CERAMIC 0.001MF	10% 50V
R525	1-215-455-00	METAL 27K 1%	1/6W	C633	1-123-024-00	ELECT 33MF	160V
R526	1-249-435-11	CARBON 33K 5%	1/6W	C634	<u>A</u> .1-162-578-51	CERAMIC 0.0047MF	20% 400V
R527	1-249-422-11	CARBON 2.7K 5%	1/6W	C636	<u>A</u> .1-136-360-51	FILM 0.22MF	20% 250V
R528	1-247-845-00	CARBON 3.9K 5%	1/6W	C637	<u>A</u> .1-136-360-51	FILM 0.22MF	20% 250V
R529	1-215-461-00	METAL 47K 1%	1/6W	C641	1-102-074-00	CERAMIC 0.001MF	10% 50V
<u>VARIABLE RESISTOR</u>				C642	1-124-903-00	ELECT 1MF	20% 50V
RV501	1-228-160-11	RES, ADJ, METAL GLAZE 5K		<u>DIODE</u>			
RV502	1-230-626-41	RES, ADJ, CARBON 470		D601	<u>A</u> .8-719-503-06	DIODE S3WB60Z	
RV503	1-230-626-41	RES, ADJ, CARBON 470		D603	8-719-925-06	DIODE ERC25-06S	
*****				D604	8-719-901-93	DIODE V19E	
*A-1245-341-A F BOARD, COMPLETE				D605	8-719-110-41	DIODE RD15ES-B2	
*****				D606	8-719-300-76	DIODE RH1A	
*4-363-404-00 HOLDER, IC				D607	8-719-109-93	DIODE RD6.2ES-B2	
<u>CAPACITOR</u>				D608	8-719-300-76	DIODE RH1A	
C601	<u>A</u> .1-136-360-51	FILM 0.22MF	20% 250V	D609	8-719-911-19	DIODE 1SS119	
				D611	8-719-200-02	DIODE 10E2	
				D612	8-719-901-93	DIODE V19E	
				D613	8-719-911-19	DIODE 1SS119	
				<u>CONNECTOR</u>			
				F1	*1-508-767-00	5P PLUG	
				F3	*1-508-786-00	2P PLUG (M)	
				F5	*1-506-348-XX	3P PLUG (L)	

The components identified by shading and mark A are critical for safety. Replace only with part number specified.

F

A

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
F6	*1-506-348-XX	3P PLUG (L)		R631	△.1-205-763-11	CEMENTED 3.3 10% 10W	F
<u>FUSE</u>				R632	1-202-733-00	SOLID 15M 10% 1/2W	
F601	△.1-532-237-11	FUSE, TIME-LAG 3.15A/250V		R633	1-247-829-00	CARBON 820 5% 1/6W	
	1-533-189-11	HOLDER, FUSE; F601		R635	△.1-246-521-75	CARBON 100K 5% 1/4W	
<u>IC</u>				R636	△.1-246-521-75	CARBON 100K 5% 1/4W	
IC601	8-759-100-75	IC UPC1394C		R638	△.1-214-937-81	METAL 1M 1% 1/2W	
<u>COIL</u>				<u>VARIABLE RESISTOR</u>			
L601	1-408-225-00	MICRO INDUCTOR 3.3UH		RV601	1-230-231-11	RES, ADJ, CERAMIC CARBON 2.2K	
L602	1-408-225-00	MICRO INDUCTOR 3.3UH		<u>TRANSFORMER</u>			
L603	1-407-365-00	COIL, CHOKE		T601	△.1-421-776-11	LFT	
L604	1-408-225-00	MICRO INDUCTOR 3.3UH		T602	△.1-448-575-11	S.R.T (CONVERTER TRANSFORMER)	
L605	1-459-215-00	CORE COIL		T603	1-446-194-00	TRANSFORMER, CHOPPER DRIVE	
<u>TRANSISTOR</u>				T604	△.1-421-783-11	TRANSFORMER, LINE FILTER	
Q601	8-729-206-04	TRANSISTOR 2SD1554		<u>THERMISTOR</u>			
Q602	8-729-195-82	TRANSISTOR 2SC2958		THP601	△.1-806-165-11	THERMISTOR (POSITIVE)	
Q603	8-729-178-54	TRANSISTOR 2SC2785		*****			
Q604	8-729-178-54	TRANSISTOR 2SC2785		*A-1296-189-A A BOARD, COMPLETE			
<u>RESISTOR</u>				*****			
R601	1-205-893-11	CEMENTED 330 5% 20W		<u>CONNECTOR</u>			
R602	1-205-687-00	CEMENTED 54K 10% 7W		A1	*1-560-123-00	PLUG, CONNECTOR (2.5MM) 3P	
R603	1-215-929-11	METAL OXIDE 100K 5% 3W	F	A2	*1-560-127-00	PLUG, CONNECTOR (2.5MM) 7P	
R604	1-247-805-00	CARBON 82 5% 1/6W		A5	*1-560-126-00	PLUG, CONNECTOR (2.5MM PITCH)	
R605	1-247-851-00	CARBON 6.8K 5% 1/6W		A6	*1-560-290-00	PLUG, CONNECTOR (2.5MM PITCH)	
R606	1-247-889-00	CARBON 270K 5% 1/6W		<u>CAPACITOR</u>			
R607	1-215-896-00	METAL OXIDE 4.7K 5% 2W	F	C151	1-106-220-00	MYLAR 0.1MF 10% 100V	
R608	1-215-896-00	METAL OXIDE 4.7K 5% 2W	F	C153	1-123-617-00	ELECT 10MF 20% 16V	
R609	1-246-520-00	CARBON 91K 5% 1/4W		C154	1-124-902-00	ELECT 0.47MF 20% 50V	
R610	1-247-866-00	CARBON 30K 5% 1/6W		C155	1-123-617-00	ELECT 10MF 20% 16V	
R611	1-249-437-11	CARBON 47K 5% 1/6W		C156	1-124-445-00	ELECT 100MF 20% 16V	
R612	1-247-819-00	CARBON 330 5% 1/6W		C157	1-123-617-00	ELECT 10MF 20% 16V	
R613	1-249-437-11	CARBON 47K 5% 1/6W		C158	1-108-849-00	MYLAR 0.1MF 10% 50V	
R614	1-247-895-00	CARBON 470K 5% 1/6W		C159	1-108-599-00	MYLAR 0.068MF 10% 50V	
R615	1-249-433-11	CARBON 22K 5% 1/6W		C160	1-124-896-00	ELECT 33MF 20% 16V	
R616	1-249-429-11	CARBON 10K 5% 1/6W		C161	1-101-004-00	CERAMIC 0.01MF 50V	
R617	1-247-840-00	CARBON 2.4K 5% 1/6W		C168	1-101-004-00	CERAMIC 0.01MF 50V	
R618	1-249-437-11	CARBON 47K 5% 1/6W		C169	1-101-004-00	CERAMIC 0.01MF 50V	
R619	1-249-429-11	CARBON 10K 5% 1/6W		C170	1-101-004-00	CERAMIC 0.01MF 50V	
R620	1-249-441-11	CARBON 100K 5% 1/6W		C201	1-102-125-00	CERAMIC 0.0047MF 10% 50V	
R621	1-247-712-11	CARBON 820 5% 1/4W		C203	1-124-903-00	ELECT 1MF 20% 50V	
R622	1-247-815-00	CARBON 220 5% 1/6W		C204	1-124-896-00	ELECT 33MF 20% 16V	
R623	1-247-891-00	CARBON 330K 5% 1/6W		C205	1-123-321-00	ELECT 220MF 20% 16V	
R624	1-247-717-11	CARBON 2.2K 5% 1/4W		C206	1-123-332-00	ELECT 47MF 20% 16V	
R625	△.1-247-289-11	CARBON 8.2M 5% 1W		C251	1-124-555-00	ELECT 1000MF 20% 16V	
R626	1-249-433-11	CARBON 22K 5% 1/6W		C252	1-102-119-00	CERAMIC 0.0015MF 10% 50V	
R627	1-217-197-11	WIREWOUND 0.56 10% 2W	F	C253	1-124-904-00	ELECT 2.2MF 20% 50V	
R628	1-244-943-00	CARBON 820K 5% 1/2W		C254	1-123-332-00	ELECT 47MF 20% 16V	
R629	1-249-441-11	CARBON 100K 5% 1/6W					
R630	1-247-891-00	CARBON 330K 5% 1/6W					

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

KV-1442ECPS

RM-651

A

C

Ref.No.	Part No.	Description	Remark	Ref.No.	Part No.	Description	Remark
C255	1-124-475-11	ELECT 470MF	20% 16V	R253	1-249-421-11	CARBON 2.2K 5%	1/6W
C256	1-108-849-00	MYLAR 0.1MF	10% 50V	R254	1-249-447-11	CARBON 1 5%	1/4W
C259	1-124-904-00	ELECT 2.2MF	20% 50V	R255	1-217-430-00	FUSIBLE 4.7 5%	1/2W F
C260	1-124-445-00	ELECT 100MF	20% 16V	R259	1-249-460-11	CARBON 15K 5%	1/4W
C261	1-102-074-00	CERAMIC 0.001MF	10% 50V	R260	1-247-713-11	CARBON 1K 5%	1/4W
C901	1-101-003-00	CERAMIC 0.0047MF	50V	<u>TUNER</u>			
<u>DIODE</u>				TU151A	1-463-577-11	TUNER, ET (BT-883A)	
D154	8-719-109-89	DIODE RD5.6ES-B2		*****			
D201	8-719-110-17	DIODE RD10ES-B2		*A-1330-757-A C BOARD, COMPLETE			
<u>IC</u>				*****			
IC251	8-759-101-77	IC UPC1241H		1-526-819-11	SOCKET, CRT		
<u>IF BLOCK</u>				*4-374-912-01	COVER (MAIN), CV VOL		
IF201	1-464-553-11	IF BLOCK (IFB-389)		*4-374-913-01	COVER (REAR LID), CV VOL		
<u>COIL</u>				<u>CONNECTOR</u>			
L152	1-408-418-00	MICRO INDUCTOR 56UH		C1	*1-506-371-00	2P PLUG (L)	
L201	1-408-397-00	MICRO INDUCTOR 1UH		C2	*1-508-786-00	2P PLUG (M)	
<u>TRANSISTOR</u>				C3	*1-560-126-00	PLUG, CONNECTOR (2.5MM) 6P	
Q151	8-729-900-61	TRANSISTOR DTA114ES		C4	*1-508-765-00	3P PLUG (M)	
Q152	8-729-900-61	TRANSISTOR DTA114ES		<u>CAPACITOR</u>			
Q153	8-729-900-61	TRANSISTOR DTA114ES		C702	1-102-114-00	CERAMIC 470PF	10% 50V
Q157	8-729-178-54	TRANSISTOR 2SC2785		C703	1-102-111-00	CERAMIC 270PF	10% 50V
Q201	8-729-212-02	TRANSISTOR 2SC2120-Y		C704	1-102-112-00	CERAMIC 330PF	10% 50V
Q202	8-729-117-54	TRANSISTOR 2SA1175		C705	1-162-116-00	CERAMIC 680PF	10% 2KV
Q251	8-729-378-84	TRANSISTOR 2SD788		C706	1-129-714-00	FILM 0.01MF	10% 630V
<u>RESISTOR</u>				C716	1-102-244-00	CERAMIC 220PF	10% 500V
R152	1-249-433-11	CARBON 22K 5%	1/6W	<u>COIL</u>			
R154	1-249-429-11	CARBON 10K 5%	1/6W	L704	1-408-452-31	MICRO INDUCTOR 68UH	
R156	1-249-435-11	CARBON 33K 5%	1/6W	<u>TRANSISTOR</u>			
R157	1-247-891-00	CARBON 330K 5%	1/6W	Q701	8-729-326-11	TRANSISTOR 2SC2611	
R159	1-247-708-11	CARBON 470 5%	1/4W	Q702	8-729-326-11	TRANSISTOR 2SC2611	
R165	1-247-823-00	CARBON 470 5%	1/6W	Q703	8-729-326-11	TRANSISTOR 2SC2611	
R171	1-247-823-00	CARBON 470 5%	1/6W	<u>RESISTOR</u>			
R172	1-247-823-00	CARBON 470 5%	1/6W	R701	1-249-422-11	CARBON 2.7K 5%	1/6W
R173	1-247-823-00	CARBON 470 5%	1/6W	R703	1-247-817-00	CARBON 270 5%	1/6W
R174	1-247-823-00	CARBON 470 5%	1/6W	R704	1-249-423-11	CARBON 3.3K 5%	1/6W
R201	1-247-713-11	CARBON 1K 5%	1/4W	R705	1-202-824-00	SOLID 3.3K 10%	1/2W
R202	1-247-873-00	CARBON 56K 5%	1/6W	R706	1-216-463-00	METAL OXIDE 12K 5%	2W F
R203	1-249-435-11	CARBON 33K 5%	1/6W	R707	1-249-420-11	CARBON 1.8K 5%	1/6W
R206	1-249-417-11	CARBON 1K 5%	1/6W	R708	1-247-821-00	CARBON 390 5%	1/6W
R208	1-249-417-11	CARBON 1K 5%	1/6W	R709	1-249-414-11	CARBON 560 5%	1/6W
R209	1-249-405-11	CARBON 100 5%	1/6W	R710	1-249-423-11	CARBON 3.3K 5%	1/6W
R220	1-217-387-00	FUSIBLE 10 5%	1/4W F	R711	1-202-824-00	SOLID 3.3K 10%	1/2W
R221	1-247-823-00	CARBON 470 5%	1/6W	R712	1-216-463-00	METAL OXIDE 12K 5%	2W F
R251	1-247-819-00	CARBON 330 5%	1/6W	R713	1-249-420-11	CARBON 1.8K 5%	1/6W
R252	1-249-433-11	CARBON 22K 5%	1/6W	R714	1-247-821-00	CARBON 390 5%	1/6W
				R715	1-249-414-11	CARBON 560 5%	1/6W
				R716	1-249-423-11	CARBON 3.3K 5%	1/6W

The components identified by shading and mark A are critical for safety. Replace only with part number specified.

Ref.No.	Part No.	Description	Remark
R717	1-202-824-00	SOLID 3.3K 10% 1/2W	
R718	1-216-463-00	METAL OXIDE 12K 5% 2W	F
R719	1-202-842-91	SOLID 220K 10% 1/2W	
R720	1-202-719-00	SOLID 1M 10% 1/2W	
R721	1-216-341-11	METAL OXIDE 0.22 5% 1W	F

R722	1-202-848-00	SOLID 680K 10% 1/2W	
R723	1-202-838-00	SOLID 100K 10% 1/2W	
R724	1-249-419-11	CARBON 1.5K 5% 1/6W	
R731	1-249-405-11	CARBON 100 5% 1/6W	
R732	1-249-405-11	CARBON 100 5% 1/6W	
R733	1-249-405-11	CARBON 100 5% 1/6W	

VARIABLE RESISTOR

RV701	1-228-723-00	RES, ADJ, CERAMIC CARBON 4.7K	
RV702	1-228-721-00	RES, ADJ, CERAMIC CARBON 2.2K	
RV703	1-228-723-00	RES, ADJ, CERAMIC CARBON 4.7K	
RV704	1-228-721-00	RES, ADJ, CERAMIC CARBON 2.2K	
RV705	1-228-723-00	RES, ADJ, CERAMIC CARBON 4.7K	

RV706	1-230-641-11	RES, ADJ, METAL GLAZE 2.2M	
RV707	1-230-641-11	RES, ADJ, METAL GLAZE 2.2M	
RV708	1-230-798-11	RES, ADJ, METAL GLAZE 90M	
RV709	1-228-725-00	RES, ADJ, CERAMIC CARBON 22K	

MISCELLANEOUS

△.1-426-145-13	COIL, DEGAUSSING	
L902 △.1-451-249-31	DEFLECTION YOKE (SY-125B)	
1-452-032-00	MAGNET, DISK; 10MM Ø	
1-452-094-00	MAGNET, ROTATABLE DISK; 15MM Ø	
1-452-277-00	MAGNET, BMC	
1-503-344-21	SPEAKER	
△.1-534-817-61	CORD, POWER	
*1-558-539-11	CABLE, P-P	
△.1-563-204-12	SOCKET, ANTENNA (PAL/SECAM)	
S901 △.1-554-966-12	SWITCH, PUSH (AC POWER)(1 KEY)	
V901 △.8-735-553-05	CRT (A34JBU10X)	

ACCESSORIES AND PACKING MATERIALS

Part No.	Description	Remark
A-1470-742-A	COMMANDER ASSY (RM-651)	
1-501-329-11	ANTENNA, TELESCOPIC	
1-513-382-00	ANTENNA MUTCHING	
4-374-990-01	CUSHION (UPPER) (ASSY)	
4-374-991-01	CUSHION (LOWER) (ASSY)	
*4-378-262-01	BAG, PROTECTION	
*4-381-635-01	INDIVIDUAL CARTON	
4-482-226-11	MANUAL, INSTRUCTION	

The components identified by shading and mark △ are critical for safety. Replace only with part number specified.

HARDWARE NOMENCLATURE

Screw:

P 3 x 10

L: Length in mm

D: Diameter in mm

Type of head

Indicated slotted-head only.

Unless otherwise indicated, it means cross-recessed head (Phillips type).



Nut, Washer, Retaining ring:

N 3

Diameter of usable screw or shaft

Reference designation

Reference Designation	Shape	Description	Remarks
SCREWS			
P		pan-head screw	binding-head (B) screw for replacement
PWH		pan-head screw with washer face	binding-head (B) screw and flat washer for replacement
PS PSP		pan-head screw with spring washer	binding-head (B) screw and spring washer for replacement
PSW PSPW		pan-head screw with spring and flat washers	binding-head (B) screw and spring and flat washers for replacement
R		round-head screw	binding-head (B) screw for replacement
K		flat-countersunk-head screw	
RK		oval-countersunk-head screw	
B		binding-head screw	
T		truss-head screw	binding-head (B) screw for replacement
F		flat-fillister-head screw	
RF		fillister-head screw	
BV		brazier-head screw	

Reference Designation	Shape	Description	Remarks
SELF-TAPPING SCREWS			
TA		self-tapping screw	ex: TA, P 3 x 10
PTP		pan-head self-tapping screw	binding-head self-tapping (TA, B) screw for replacement
PTPWH		pan-head self-tapping screw with washer face	binding-head self-tapping (TA, B) screw and flat washer for replacement
PTTWH		pan-head thread-rolling screw with washer face	binding-head (B) screw and flat washer for replacement
SET SCREWS			
SC		set screw	
SC		hexagon-socket set screw	ex: SC 2.6 x 4, hexagon socket
NUT			
N		nut	
WASHERS			
W		flat washer	
SW		spring washer	
LW		internal-tooth lock washer	ex: LW3, internal
LW		external-tooth lock washer	ex: LW3, external
RETAINING RINGS			
E		retaining ring	
G		grip-type retaining ring	

SONY

TRINITRON® COLOUR TV

KV-1442ECPS/RM-651

West Germany Model

Chassis No. SCC-788A-A

XE-5 CHASSIS


SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARK  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.




Note:

- All capacitors are in μF unless otherwise noted. pF : $\mu\mu\text{F}$ 50WV or less are not indicated except for electrolytics
- All resistors are in ohms, $\frac{1}{6}\text{ W}$ unless otherwise noted. k Ω : 1000 Ω , M Ω : 1000k Ω
-  : nonflammable resistor.
-  : fusible resistor.
-  : internal component.
-  : panel designation.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- no mark : PAL
() : SECAM
- Readings are taken with color-bar signal input.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken with a 10M Ω digital multimeter.
- Voltage variations may be noted due to normal production tolerances.
-  : B+ bus.
-  : B- bus.
-  : signal path.
- All voltage are in "V".

Note: The components identified by shading and mark  are critical for safety. Replace only with part number specified.



SCHEMATIC DIAGRAM




PRINTED WIRING BOARD

115 V ADJ


Adjust RV601 for 115±0.5 V de on the digital multimeter.

digital multimeter



F

[REF PWM]
[REG OUT]



ANTI-PAL, LINE CRAWLING ADJUSTMENT


ANTI-PAL ADJUSTMENT

1. Input the PAL SPECIAL colour bar signal.
2. Set the PICTURE, COLOUR and BRT control to center click.
3. Confirm that there is no colour on the first anti-PAL signal frames at the right and left of the picture.

If there is adjust to remove the anti-PAL colour at both side while tracking with RV302 (DELAY) and RV303 (PHASE).

LINE CRAWLING ADJUSTMENT

1. Input a PAL colour bar.
2. Set the PICTURE, COLOUR and BRT control to center click.
3. Observe the B-5 (4) (Blue) output waveform shown in the oscilloscope.
4. Adjust T301 for minimum line crawling.




B

[CPU, MEMORY, Y/C PROCESS]
[H. V OUT]


C

[R. G. B OUT]




D

[H. V. JUNGLE]



H-FREQ ADJUSTMENT

1. Input the PAL color bar signal.
2. Set the PICTURE, COLOUR and BRT control to center click.
3. Short circuit between pin 11 and pin 12 of IC301.
4. Adjust RV501 for the image size to center click.
5. Remove a jumper wire.
6. Change tuner channel and confirm the change.



V-size V-LINE V-CENT

Adjust RV502, RV503 and RV504 picture.

H-SIZE ADJUSTMENT


Adjust L806 for best size picture.

A-P-C ADJUSTMENT

1. Input the PAL colour bar signal.
2. Set the PICTURE COLOUR and BRT control to center click.
3. Short circuit between pin 11 and pin 12 of IC301 with a jumper wire.
4. Adjust CV301 for suitable colour intensity.
5. Remove a jumper wire.

ACC ADJUSTMENT


1. Input the PAL colour bar signal.
2. Set the PICTURE, COLOUR and BRT control to center click.
3. Observe IC301 pin 7 waveform and adjust RV304 (ACC) so that the waveform level is 180 ± 10m Vp-p.



D

[H. V. JUNGLE]

(KV-1442ECPS/RM-651)



H-FREQ ADJUSTMENT

TP 33 = A-1, RV501 = A-1

1. Input the PAL color bar signal.
2. Set the PICTURE, COLOUR and BRT control to center click.
3. Short circuit between pin and pin of TP33 with a jumper wire.
4. Adjust RV501 for the image shown below.
5. Remove a jumper wire.
6. Change tuner channel and confirm that picture does not change.



fo: too low fo: suitable fo: high
(fo = 15625 ± 50Hz)

V-size V-LINE V-CENT

Adjust RV502, RV503 and RV551 for a best vertical size picture.

SIZE ADJUSTMENT


Adjust L806 for best size picture.

P-C ADJUSTMENT

Input the PAL colour bar signal.
Set the PICTURE COLOUR and BRT control to center click.
Short circuit between pin (11) and pin (12) of IC301 with a jumper wire.
Adjust CV301 for suitable colour intensity.
Remove a jumper wire.

CAPACITOR	VARIABLE RESISTOR
C501 C502 C503 C504 C506 C507 C508 C509 C510 C511	RV501 RV502 RV503
C512 C513 C514 C515 C516 C517 C518 C519 C521 C522	TP
C523 C524 C527 C530 C502	TP33
CONNECTOR	
W1	
IC	
IC501	
RESISTOR	
R501 R502 R504 R505 R506 R507 R511 R514 R515 R517	
R519 R522 R524 R525 R526 R527 R528 R529	

A

[TUNER, AF OUT]
AFT, AGC

TU AGC ADJUSTMENT


Adjust RF AGC so that snow-noise cross modulation adjust disappear from the picture.

CONNECTOR	TRANSISTOR
A1 A2 A5 A6	Q151 Q152 Q153 Q157 Q201 Q202 Q251
CAPACITOR	RESISTOR
C151 C153 C154 C155 C156 C157 C158 C159 C160 C161	R152 R154 R156 R157 R159 R160 R165 R171 R172 R173
C168 C169 C170 C201 C203 C204 C205 C206 C251 C252	R174 R201 R202 R203 R206 R208 R209 R220 R221 R251
C253 C254 C255 C256 C259 C260 C261	R252 R253 R254 R255 R259 R260
DIODE	TUNER
D154 D201	TU151
IC	
IC251	
IF	
IF201	
COIL	
L152 L201	


BX-1398




CX20061




CX20100





μPC1377C



μPC1394C



2SC2785TP

2SC2958
2SC2959
2SD773
2SD774

2SD1134






HZS10NB2T2
HZS11NT2
HZS11NB1T2
HZS11NB2T2
HZS11NB3T2
HZS13NB2T2
HZS15NT2
HZS15NB1T2
HZS15NB2T2
HZS15NB3T2
HZS5.6NT2
HZS5.6NB1T2
HZS5.6NB2T2
HZS5.6NB3T2



DTA114ES
DTA124ES
DTA124XS
DTC144ES
2SA1048TP

1. Input a PAL colour bar.
2. Set the PICTURE, COLOUR and BRT control to click center.
3. Observe the B-5 (4) (Blue) output waveform shown in the oscilloscope.
4. Adjust T301 for minimum line crawling.


- click.
3. Observe IC301 pin (7) waveform and adjust RV304 (ACC) so that the waveform level is $180 \pm 10\text{m Vp-p}$.



Adjust L806 for best size picture.

1. Input the PAL colour bar signal.
2. Set the PICTURE COLOUR and BRT control to center click.
3. Short circuit between pin (11) and pin (12) of IC301 with a jumper wire.
4. Adjust CV301 for suitable colour intensity.
5. Remove a jumper wire.

B

[CPU, MEMORY, Y/C PROCESS
H. V OUT[illegible]

